

## Installation Instruction

The Shower is built with bottom inlet

### Top Inlet Installation Instruction

To change into top inlet, unscrew both cap and water inlet connector behind back of shower body, swap over cap and water inlet connector and screw it in.

Follow the Diagram below:



